## Scoreboard Operator's Instructions MPC Control

### Turning Machine on
- Turn on (button on the side)
- Model Code 871
- If prompted may need to select (Alternate Time control > **TIME OFF**) on the bottom left of the machine

### To Set Time
- Set > Time > (Insert Time ex:12:00) > Yes > (Period #) > Yes
- To Start clock flip switch on handheld device on, to stop flip switch opposite direction.

### To Set Score
- Press Set > Home Score > (enter score) > Yes.
- Press Set > Guest Score > (enter score) > Yes.

### Penalty
- Press SET then HOME PENALTY to set up a penalty.
- The control will prompt [_PEN MM:SS _]. Enter the penalty time (up to 19:59). Press **NO** to cancel, or **YES** to confirm.
- The control will prompt [_H.PLAYER # _]. Enter the 2 digit player number (_0 to 99).
- Guest Penalties work the same way.
- Press PENALTY EDIT to edit the displayed penalty
  - The control will prompt [_ EDIT (Y-N) Press **NO** to cancel, or **YES** to confirm.
  - The control will prompt [_PEN MM:SS _]. Enter the penalty time (up to 19:59). Press **NO** to cancel, or **YES** to confirm.
- Press PENALTY CLEAR to clear the displayed penalty Press **NO** to cancel, or **YES** to confirm.

749 River Valley Drive, Grand Bay-Westfield, NB E5K 1B6